



**FEDERATION
EUROPEENNE DE LA
MANUTENTION**
Product Group Cranes
and Lifting Equipment

FEM
5.014
Edition 1
13.03.2013

**External Warning signals of the Rated Capacity Limiter,
speed reductions and Event Recorder for mobile cranes**

**Externe Warnsignale der Lastmomentbegrenzung,
Geschwindigkeitsreduktion und Event Recorder für
Mobilkrane**

**Signalisation extérieure du Contrôleur d'État de Charge,
réduction de vitesse et enregistrement de données pour
grues mobiles**

Fédération Européenne de la Manutention - Product Group Cranes and Lifting Equipment

Copyright: FEM PG CLE

Available in English (E)

Sources see end of the document

CONTENT

	Page
1 INTRODUCTION	3
2 SCOPE	3
3 REQUIREMENTS FOR RCL COMPLIANT WITH EN13000:2010	3
4 EXPLANATION AND POSSIBLE CONTENT OF OPERATOR'S MANUAL.....	3
Table: RCL requirements	4
References.....	5

1 INTRODUCTION

The main goal of this document is to provide design rules for a standard way to warn people in the vicinity of the crane about the actual load status of the machine. In contrary to the warning signals inside the cabin (seen only by the operator who well knows the machine and its specific features), it is crucial to ensure a common warning concept for people surrounding the crane (these persons don't know the crane brand or type and are not even supposed to have any skills about cranes); therefore, a standard warning philosophy was necessary to increase job site safety.

2 SCOPE

This document applies to mobile cranes and is considered as a complementary rule to EN13000:2010, chapters 4.2.6.3.3 and 4.2.6.3.4.

3 REQUIREMENTS FOR RCL COMPLIANT WITH EN13000:2010

FEM Manufacturers have defined detailed functionalities for the Rated Capacity Limiter. These features are complementary to the specifications described in EN13000:2010.

The table below describes these requirements.

NOTE: In setup mode, the speed reduction for ALL movements has been defined in order to avoid misuse of this function; setup mode shall only be used for rigging/de-rigging or in case of deadlock. The setup button shall not be used during regular lifting operation or as "capacity booster".

The warning signals and their hierarchy described in the table have been defined under following considerations:

- Movement cut-off such as from a hoist limiter are not signalized with external visual or external audible warning since it is to be considered that such cut off do not lead to a hazardous situation.
- Situations where the crane loading is beyond the permissible limits (overload) and is not limited any longer by safety devices (e.g. RCL overridden) correspond to the highest warning level and the corresponding warning signal shall be dedicated to this warning.

4 EXPLANATION AND POSSIBLE CONTENT OF OPERATOR'S MANUAL

In case of an emergency during setup mode, the operator can deactivate the setup-mode and will then get back to "normal operation"; he'll then have the possibility to get out of the overload situation at normal speed and return to a condition with reduced risk as required by the product standard EN13000.

The deactivation of the setup button when the load is above 100% shall only be used in case of emergency situation; when getting back into the "normal Operation" mode with a load exceeding 100%, the RCL will automatically trigger the event recorder and the audible and visual warnings inside and outside the cabin.

After any overloading, it is highly recommended to proceed with a thorough examination of the load bearing structure of the crane.

Table: RCL requirements

Mode	Phase	Limits	Movement possible / Speed		Event record	Warning OUTSIDE cabin		
			Load increasing movement	Load neutral or load decreasing movement		VISUAL		AUDIBLE
						3 colour light	single colour light	
OPERATION	normal	load < 90%	YES 100%	YES 100%	NO	Constant green	no light	no sound
	approach	90% <= load <=100%	YES 100%	YES 100%	NO	Constant yellow	no light	no sound
	overload	load >100%	NO	YES 100%	YES	Constant red	Flash red	sound intermittent, cancelable after 5s
SETUP Setup Button activated	Set-up mode Load Charts available LMI active	load < 90%	YES 15%*	YES 15%*	YES	Constant green	no light	no sound
		90% <= load <=100%	YES 15%*	YES 15%*	YES	Constant yellow	no light	no sound
		100% < load <=110%	YES 15%*	YES 15%*	YES	Flash yellow	no light	no sound
		load >110%	NO	YES 15%*	YES	Constant red	Flash red	sound intermittent, cancelable after 5s
	(De)Rigging procedure no loads allowed No Load Chart available	No max Load indication if possible: specific movement cut offs for monitoring of (de)rigging	YES 100%	YES 100%	YES	Flash yellow	Flash red	no sound
EMERGENCY Bridging Device	Bridging Device (outside cabin) in case of: - Failure of components - Emergency Situation	LMI inactive Any load status	YES 15%*	YES 100%**	YES	Flash red	Flash red	sound constant, not cancelable

* For mobile cranes where the actuating device controls the hydraulic pressure and where the speed reduction is provided by a central control pressure reduction, the speed shall be reduced to max. 25%

** The speed reduction can be applied to all movements for mobile cranes where the actuating device controls the hydraulic pressure. Due to the wide range of crane types in the scope of EN13000, the manufacturer may define a lower permissible speed.

References

Established by the Technical Committee of Product Group Cranes and Lifting Equipment of the Fédération Européenne de la Manutention (FEM)

Secretariat: **Secretariat of FEM Product Group Cranes and Lifting Equipment**
c/o VDMA
Materials Handling and Logistic Technology Association
Lyoner Str. 18
D-60528 Frankfurt

Available from web server of FEM (Publishing House): <http://fem.vdma-verlag.de>

FEM Member Associations:

Belgium, AGORIA

Finland, Technology Industries of Finland

France, CISMA

Germany, VDMA

Italy, AISEM

Luxembourg, Industrie Luxembourgeois de la Technologie du Métalp. a. FEDIL

Netherlands, ME-CWM

Portugal, ANEMM

Spain, FEM-AEM - E.T.S.E.I.B

Switzerland, SWISSMEM

Sweden, TEKNIKFÖRETAGEN

Turkey, ISDER

United Kingdom, BMHF

For more information regarding FEM, please visit the FEM Website:

<http://www.fem-eur.com>